

IRH-281 Two Channel Infrared Headsets

1/16/15

The IRH-281 headsets receive “Hearing Impaired” audio (dialog centric audio at a user adjustable loudness) and “Audio Description” audio (formerly Visually Impaired –Narrative, a description of the movie action to aid visually impaired individuals). The infrared signal carries the HI audio at 2.3 MHz and the AD signal at 2.8 MHz. The IRH-281 is powered by two AAA batteries.



Batteries

When new batteries are needed, remove the battery cover by pushing the tab up and lifting the cover off.



Install AAA batteries with the + (positive) end as indicated above. Re-install battery cover.

Adjustable Headband

Adjust the headband to the size needed for the individual patron by pulling or pushing the ear pieces.



Controls

Use the ON/OFF switch to turn the unit ON or OFF. Adjust the “Hearing Impaired” channel (Volume A) and/or the “Audio Description” channel (Volume B) as desired to achieve a comfortable listening level. The IRH-281 allows a blend of HI and AD to be heard with the mix adjusted by the patron. The monitor switch will mute the sound while the monitor button is held in. The patron may use the headset as a receiver by plugging in their personal neck loop or earphones into the jack. If left on, and the headsets are not receiving a signal, the headsets will shut OFF after 5 minutes.



